

# Specifications

## OPERATION

- Lever style handle with temperature indicator on the escutcheon
- Handle operates counterclockwise through a 120° arc with off at 6 o'clock and maximum hot at the 2 o'clock position. Shut off in clockwise direction
- Adjustable temperature limit stop to control maximum hot water temperature
- Pressure balancing mechanism maintains selected discharge temperature to  $\pm 3.6^{\circ}\text{F}(\pm 2^{\circ}\text{C})$


## FLOW

- Showerhead is limited to 2.5gpm(9.5L/min) at 80psi
- Bathtub spout is minimum to 2.4gpm(9.0L/min) at 20psi

## CARTRIDGE



- Pressure Balance cartridge

## STANDARDS



- Third party certified to meet ASME A112.18.1 all applicable requirements referenced therein
- ADA  for lever handle

## WARRANTY

- Lifetime limited warranty against leaks, drips and finish defects to the original consumer purchaser
- 5 year warranty if used in commercial installations




Concealed Shower Set




CRITICAL DIMENSIONS

# Concealed Shower Set Installation


## INSTALLATION MANUAL Tools You Will Need :




Adjustable wrench



Hexagon wrench




Phillips Screwdriver




Pipe Tape

### Notes before installation :


1. Please check that all components are present.
2. Before installation ensure that all feed lines are clear of debris and on/off valve is present.
3. Ensure water pressure is between 20-125 PSI (includes combination of hot and cold feed lines).
4. Pictures in the manual are general in content and may not represent exactly your purchased faucet. If you are having difficulties please contact a professional plumber.
5. If you will be away from home for an extended period you should shut off the main water supply.




1. Confirm the installed place of the pressure balance valve and fixed on the wood block .




2. Connect the hot&cold inlet tube and outlet tube, then make sure the tube fix stable on the wooden wall.




3. Lock the install protective cover into the body.( $\Phi$ 140mm round type).




4. Please cut the size of the tile hole according to the size and shape of the protective cover ( about 5mm bigger than the protective cover from each side ) . And please put the tile outside the wooden wall ( please noted that we keep the same central point for the tile hole with the protective cover ) .




5. Loosen the screw and remove the protective cover.



6. Lock the deck plate into the body and cling to the wall, then tighten the screw.



7. Put on the handle, then tighten the screw.



8. Install the shower arm, shower head and flange to the fitting. (stick to the wall) . Tighten the showerhead to the shower arm with the pipe tape. (Make sure the pipe tape with clockwise direction) .